

Olympus C-3040 Instructions for OneShot360

Recommended Camera Settings for OneShot360

- Attach the Oneshot360 unit, and power the camera on in A/S/M mode
- Use the Zoom to exactly fill the digital camera LCD viewer screen with the circular image. This is done by using the zoom lever on the front of the camera. If you zoom in too much, you will lose part of the field of view. If you zoom in too little, you will not get maximum resolution. Note also that the OneShot image may not be exactly centered in the LCD screen – this is normal.
- Make sure the flash is disabled by pressing the flash mode button (lightening bolt) located above the LCD screen until you see the "flash off" icon on the LCD.
- To focus your OneShot image with the Olympus C-3040 camera, press the menu button and using the toggle Arrow keys pad select MF under the AF/MF mode. We recommend a setting of 10 feet. You can select the distance by toggling with the Arrow Pad and pressing the OK button.
- Then adjust the Arrow Pad up/down to set aperture to an f-stop of 7.0.

*NOTE: Aperture priority mode may not be suitable for low light or some indoor shooting conditions because the camera will not allow a shutter speed slower than 1/30 of a second while in this mode. This would mean the image would not be properly exposed if using a small aperture. To work around this limitation, you can use shutter priority mode, and use a shutter speed that would give you the desired f-stop #. Also, make sure you are using a tripod when shooting with a slow shutter speed.

Press the MENU button and use arrow buttons to:

- Under the WB menu, set the white balance. Auto is usually fine for most shots.
- Under the Mode Set-up/Set-up/TIF/ set the image size to 2048x1536 for best quality.
- Under the Mode Set-up/Set-up/ set the Sharpness to Normal for best compromise between tonal range and contrast.
- Select the self timer under Main Menu/Drive/Self Timer.

Contact: Metropole360 Email: support@metropole360.com Web: <u>http://www.metropole360.com</u> Phone: 212-980-2427